


# Steel Round Gazebo

Assembly Instructions - Please keep for future reference

Product Code: 16079



## THANK YOU FOR CHOOSING THIS GARDEN COLLECTION PRODUCT.

Please read this instruction manual carefully before beginning to assemble the product. This is an important document, please read carefully and keep safely for future reference.



### CAUTION

THIS BAG IS NOT A TOY.  
PLASTIC BAGS CAN BE DANGEROUS.  
TO AVOID DANGER OF SUFFOCATION,  
KEEP THIS BAG AWAY FROM BABIES  
AND CHILDREN.  
DESTROY BAG BEFORE DISCARDING.

## NECESSARY TOOLS

Please check the package contents before attempting to assemble this product. A full checklist of components is given in this leaflet. If any components are missing, please contact the retailer from whom you bought this product.



The fittings pack contains SMALL ITEMS that could be swallowed, these parts should be **KEPT AWAY FROM YOUNG CHILDREN.**

## DISTRIBUTED BY




United Hardware,  
Magna Drive, Magna Business Park,  
Citywest Road, Dublin 24,  
Ireland - D24 KX97

✉ [info@unitedhardware.ie](mailto:info@unitedhardware.ie)

🌐 [www.unitedhardware.ie](http://www.unitedhardware.ie)

# Assembly Instructions

φ3.6M



This Gazebo is intended for domestic use only.

We recommend assembly by four or more capable adults under light or no wind conditions.

## CARE TIPS

**Cleaning:** Clean with a damp cloth, do not use bleach or harsh chemicals

**Storage:** Do not leave this product up in windy conditions, use only in light or no wind. Store in a cool dry place. Avoid exposure to moisture to prevent rust.

**Inspection:** Ensure that the product is erected correctly before use and that all hardware is tightened before each use.

## SAFETY STATEMENTS AND WARNINGS

**Do not use** this gazebo under windy conditions. Always secure the gazebo while using.

This is not a permanent structure and should be disassembled and stored away

**Do not** repack your gazebo if wet, allow to dry completely first.

## FIRE PRECAUTIONS

**Do not use** firepits, gas or electric heaters, candles, radiators or any other type of heat or fire source, or flammable liquid in or around the gazebo.























**Do not use** naked flames in or around the gazebo.

**Do not** cook or use a BBQ in or around the gazebo

## WARNING


The manufacturer and seller disclaim any and all liability from personal injury, property damage or loss, whether direct or indirect or incidental resulting from the incorrect assembly, improper use, inadequate maintenance or neglect of this product.

# Assembly Instructions


			2#		6PCS						
			3#		6PCS						
			4#		6PCS						
			5#		6PCS						
1#		6PCS		6#		6PCS					
		21#		6PCS				7#		1PC	
		8#		1PC				9#		6PCS	
		14#		90PCS				10#		12PCS	
		12#		12PCS				11#		48PCS	
		13#		60PCS				15#		6PCS	
		13#		60PCS				16#		2PCS	
		13#		60PCS				17#		12PCS	
		18#		1PC				19#		1PC	
		20#		6PCS							

# Assembly Instructions

1




2




# Assembly Instructions

3



# Assembly Instructions

4



# Assembly Instructions

5

